

Onzo Guitars P16 “Try These First” card:

Mode 1, bridge Voice down

cutting lead sound for rock, punk, country and blues

Mode 2, both Voice up

rich and punchy sound for rock, R&B, metal and blues

Mode 3, neck Voice down, bridge Voice up

hollow and honky sound for rock, funk and techno

Mode 4, both Voice up

acoustic sounding voice for country, folk and all strumming

Mode 5, neck Voice down

smooth chord and lead sound for jazz and all other styles

Experiment with the Voice switches to find the best combination in each Mode family for each of the music styles listed above.